

**Quick, Easy
and
Cost Effective!**

CoFlex®·AFD

ABSORBENT FOAM DRESSING

**LATEX
FREE**

U.S. Patent Nos. 5.762.623 & 6.156.424 Patent Pending U.S. Patent No. 6.566.576 Dicon Technologies

A Better Way To Bandage!

CoFlex®·AFD
ABSORBENT FOAM DRESSING

EasyTear
PATENTED TECHNOLOGY

- Helps stop bleeding quickly
- Quick & easy application
- Wrap and go!

**Absorbs the
equivalent
of 29 gauze
pads!**



**All-in-One absorbent foam pad
and dressing**



1) Unroll CoFlex AFD
to expose foam pad.



2) Place over wound
and wrap.



3) Hand-tear, then
seal cohesive bandage
to itself.

DONE!

Traditional Bandaging Method



**Traditional bandaging method
requires a variety of products.**



1) Place gauze pads
over wound. Position
roll gauze to begin
wrapping.



2) Begin wrapping
roll gauze around
gauze pads .



3) Continue wrapping
to secure gauze pads.



4) Use scissors to
cut roll gauze.



5) Hold roll gauze
in place while tearing
tape from roll.



6) Traditional
bandaging complete!